((

SUMAKE PNEUMATIC TOOLS



Air D-Ring Gun ATR30S

SUMAKE INDUSTRIAL CO., LTD 4F,NO.351,Yangguang St.,Neihu District TAIPEI, TAIWAN, ZIP:114-91



ATR30S-S-2212A-AC

TOOL SPECIFICATIONS

MODEL OF TOOL TOOL LENGTH TOOL HEIGHT TOOL WIDTH WEIGHT (WITHOUT FASTENERS) AIR INLET	ATR30S 10.04" (255 mm) 10.43" (265 mm) 3.35" (85 mm) 3.31 lbs (1.5 kg) 1/4" NPT
COMPRESSED AIR : Maximum permissible operating pressure Recommended operating pressure range AIR CONSUMPTION	
Noise dB(A) :	
A-weighted sound pressure level LpA	
A-weighted sound power level LwA Measurement uncertainty: 3dB Vibration (m/s ²):	93.17 dB(A)
Hand-arm vibration value	3.68 m/s ²
Measurement uncertainty: 1.5 m/s ²	

Warning:

The vibration emission during actual use of the power tool can differ from the declared total value depending on the ways in which the tool is used; and of the need to identify safety measures to protect the operator that are based on an estimation of exposure in the actual conditions of use (taking account of all parts of the operation cycle such as the times when the tool is switched off and when it is running idle in addition to the trigger time).

List of fasteners for ATR30S :

Crown	Shank Height	Shank Dia.	MAGAZINE
30.0 mm , 1.18 "	14.0 mm , 0.55 "	2.0 mm , 0.078 "	50 pcs



2.0mm Foreword:

This pneumatic D-ring tool is designed for using D rings. Its well balanced, ergonomic, comfort nonslip cushioned grip and heavy duty driving ensure D ring closure to different sizes and types of round

shape. This D ring tool is best fitted in specialty applications for instance automotive, bedding, furniture, fencing and wires.

Suitable applications:

Bedding, cage, lobster pot, wire and wire like applications, automotive seating cover, upholstery foam secured to frame, attaching labels, training plant, cords, bag closure, cargo nets, small rope and many more....

Caution:

D-ring tools are ideal for applications where needs tying, fastening and tightening. Not suitable for stapling or nailing into concrete, masonry bricks or steel. Do not fire if nails are jammed, as this will cause damage to the D-ring tool.

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

/ WARNING

Indicates an potentially hazardous situation which, if not avoided, will result in death or serious injury.

Alerts the operator to useful information.

SAFETY INSTRUCTIONS

- Read this manual and understand all safety instructions before operation the tool. If you
 have any questions, please contact our authorized representatives.
- Only those fasteners listed in the operating instructions may be used in the fastener driving tools.
- 3. Only the main energy and the lubricants listed in the operating instructions may be used.
- Fastener driving tools marked with an inverted equilateral triangle standing on one point may only be used with an effective safety yoke.
- For the maintenance of fastener driving tools, only spare parts specified by the manufacturer or his authorized representative shall be used.
- Repairs shall carried out by agents authorized by the manufacturer or by other specialists, having due regard to the information given in the operating instruction.
- 7. Stands for mounting the fastener driving tools to a support for example a work table shall be designed and constructed by the stand manufacturer in such a way that the fastener driving tool can be safely fixed for the intended use, thus for example avoiding damage, distortion or displacement.
- 8. Fastener driving tools operated by compressed air shall only be connected to compressed air lines where the maximum allowable pressure cannot be exceed by a factor of more than 10%, which can for example be achieved by a pressure reduction valve which includes a downstream safety valve.

- When using fastener driving tools operated by compressed air, particular attention must be paid to avoid exceeding the maximum allowable pressure.
- 10. When using fastener driving tools operated by compressed air should only be operated at the lowest pressure required for the work process at hand, in order to prevent unnecessarily high noise levels, increased wear and resulting failures.
- Hazards caused by fire and explosion when using oxygen or combustible gases for operating compressed air operated fastener driving tools.
- 12. Carry the fastener driving tool at workpiece using only the handgrip, and never with the trigger actuated. Never carry the tool by the hose or pull the hose to move the tool.



13. Disconnect the tool from air supply before cleaning jams, servicing, adjusting, and during non-operation.





15. Do not use a check valve or any other fitting which allows air to remain in the tool.



16. Do not place your hand or any part of your body in the fastener discharge area of the tool when connecting or disconnecting air supply.



17. Never point tool at yourself or at any other person.

AIR SUPPLY AND CONNECTION

⚠ NOTE



- Many air tool users find it convenient to use oiler to help provide oil circulation through tool and increase the efficiency and useful life of the tool. Check oil level in the oiler daily.
- Many air tool user find it convenient to use a filter to remove liquid and impurities which can rust or wear internal parts of the tool. A filter also increase the efficiency and useful of the tool. The filter must be checked on a daily basis and if necessary drained.
- For better performance, install a 3/8" quick connector (1/4" NPT threads) with an inside diameter of .315" on your tool and a 3/8" guick coupler on the air hose.

The following illustration shows the correct mode of connection to the air supply system which will increase the efficiency and useful life of the tool.



LUBRICATION AND MAINTENANCE

· Disconnect the air supply from the tool before lubricating.

· Your tool requires lubrication before you use it for the first time.



- Wipe off excessive oil at the exhaust. Excessive oil will damage
 O-rings of tool. If in-line oiler is used, manual lubrication through the air inlet is not required on a daily basis.
- Turn the tool so the inlet is facing up and put one drop of high speed spindle oil, UNOCAL RX22, or 3-IN-1 oil into air inlet. Never use detergent oil or additives. Operate the tool briefly after adding oil.

LOADING THE TOOL



 Do not place your hand or any part of your body in the fastener discharge area of the tool when connecting or disconnecting air supply.



 Never point any operational fastener driving tool at yourself or at any other person.



1. Disconnect air hose



Depress the magazine latch. Pull back on the magazine cover.



 Insert a stick of fasteners into the magazine. Make sure the pointed ends of the fasteners are loaded with the points upward. Also make sure fasteners are not dirty or damaged.



4. Push the magazine cover forward until the latch catches.

OPERATING THE TOOL

NOTE

Protect your eyes shields. Wear hear responsible for er safety protection.

Protect your eyes and ears. Wear z87.1 safety glasses with side shields. Wear hearing protection. Employers and users are responsible for ensuring the user or anyone near the tool wear this safety protection.



- Check and replace any damaged or worn components on the tool. The safety warning labels on the tool must also be replaced if they are not legible.
- 1. Add a few drops of UNOCAL RX22 or 3-in-1 oil into the air inlet. (See Fig. 1)

2. Attach a high flow quick connect fitting to the tool. (See Fig. 2)



200 PSI WP

o − 3/8" I.D.

- 3. Empty the magazine.
- Connect the tool to an air compressor using a 3/8" I.D hose. Make sure the hose has a rated working pressure exceeding 200 PSI (13.8bar) and a female quick coupler. (See Fig. 3)
- 5. Regulate the air pressure to obtain 70 PSI (4.8 bar) at the tool. (See Fig. 4)



Fig.3

- 6. Disconnect the air supply from the tool.
 - 7. Load fasteners into your tool following the instructions in this manual. (See Fig. 5)



- 8. Reconnect the air supply to the tool.
- 9. Test for proper fastener penetration by driving nails into a sample piece of wood. If the fasteners do not achieve the desired penetration, adjust the air pressure to a higher setting until the desired penetration is achieved. Do not exceed 110 PSI (7.6 bar) at the tool. (See Fig. 6)

CLEARING A JAM FROM THE TOOL

Fastener jammed in fastener discharge area:
 Disconnect tool from air hose.

· Pull back on fastener pusher until locked.

· Grab jammed fastener with pliers and remove.

Disconnect the tool from air compressor before adjusting, clearing jams, servicing, relocating and during non-operation.





CLEANING THE TOOL

Fastener jam inside magazine:
 Disconnect air tool from air hose.

Removed jammed fastener.Release fastener pusher.

Never use gasoline or other flammable liquids to clean the tool. Va pors in the tool will ignite by a spark and cause the tool to explode and result in death or serious personal injury.

Solvents used to clean the nose of the tool and contacr safety trip mechanism may soften the tar on the shingles and cause the buildup to be accelerated. Make sure to dry the tool thoroughly after cleaning and before operating the tool again.



1. Disconnect the air supply from the tool.



 Remove tar buildup with kerosene #2 fuel oil or diesel fuel. Do not allow solvent to get into the cylinder or damage may occur. Dry off the tool completely before use.

TROUBLESHOOTING

Stop using the tool immediately if any of the following problems occur. Serious personal injury could. Any repairs or replacements must be done by a qualified person or an authorized service center only.

PROBLEM	PROBABLE CAUSE	REMEDY			
Air leaking at trigger valve area.	O-rings in trigger valve housing are damaged.	O-rings must be replaced.			
	Loose screws in housing.	Screws need to be tightened.			
Air leaking between housing and nose.	Damaged to bumper.	O-rings must be replaced.			
	Damage to bumper.	Bumper needs to be tightened.			
Air leaking between housing and cap assy.	Loose screws.	crews need to be tightened.			
	Damaged seal.	Seal needs to be replaced.			
	Worn bumper.	Bumper needs to be replaced.			
	Dirt in nose.	Clean.			
Tool skips driving fastener.	Dirt or damage prevents fasteners from moving freely in magazine.	Magazine needs to be cleaned.			
	Inadequate air flow to tool.	Fitting hose or air compressor needs to be checked.			
	Worn O-ring on piston or lack of lubrication.	O-ring needs to be replaced. Lubricate.			
1. 1.1	Damaged O-rings on trigger valve.	O-rings need to be replaced.			
17 11	Air leaks.	Screws and fittings need to be tightened.			
	Cap seal leaking.	Seal needs to be replaced.			
	Tool not lubricated sufficiently.	Tools needs to be lubricated.			
Tool runs slow or has loss of power.	Broken spring in cap assy.	Spring needs to be replaced.			
	Exhaust port in cap is blocked.	Damaged internal parts need to be replaced.			
	Driver nozzle worn or damaged.	Replace driver nozzle.			
	Driver is damaged.	Replace driver.			
Fasteners are jammed in tool.	Fasteners are not correct size.	Fasteners recommended for tool must be used.			
	Fasteners are bent.	Replace with undamaged fastener.			
	Magazine or nose screws are loose.	Screws need to be tightened.			





Fig.6

Fig.5

ATR30S Air D-Ring Gun



Part_No	Description	Spec	Q'ty	Part_No	Description	Spec	Q'ty	Part_No	Description	Spec	Q'ty
AA3401	PUSHER SPRING		1	QD0401	PAWL RIGHT		1	WV2501	ARM LEFT LINK	ĺ	1
▲ AA3501	ROLLER		1	QD0501	PAWL LEFT		1	WV2601	STOPPER		1
KK0505	HEX.SOC.SET SCREW	M5×0.8 - 5L	2	QD0601	REPLACEABLE TEETH		1	WV2701	PIN		2
KM0406	HEX.SOC.HD.BOLT	M4×0.7 - 6L	1	QD0701	SUPPORT		1	WV3301	SPACER		1
KM0412	HEX.SOC.HD.BOLT	M4×0.7 - 12L	2	WV0103	BODY		1	YB0505	STEEL BALL	∮5.5	1
KM0512	HEX.SOC.HD.BOLT	M5×0.8 - 12L	3	WV0202	TRIGGER VALVE SEAT		1	YL0610	LOCK NUT	M6×1.0	1
KM0514	HEX.SOC.HD.BOLT	M5×0.8 - 14L	2	WV0301W	DRIVER ASSY.		1	YL0812	LOCK NUT	M8×1.2	1
KM0608	HEX.SOC.HD.BOLT	M6×1.0 - 8L	1	WV0302	TRIGGER VALVE GUIDE		1	YW0401	FLAT WASHER	ф 4	2
KM0616D	HEX.SOC.HD.BOLT	M6×1.0 - 16L	1	WV0401	TRIGGER VALVE STEM		1				
KM0625	HEX.SOC.HD.BOLT	M6×1.0 - 25L	1	WV0501	COMPRESSION SPRING		1				
KR0510	BUTTON HD.BOLT	M5×0.8 - 10L	1	WV0601	FRONT STOP SPACER	A	1	~			
KS2506	SPRING PIN	∮2.5-6L	1	WV0701	FINISHED CLEVIS		1	7			
KS2510	SPRING PIN	∮2.5-10L	1	WV0801	ROD PISTON	7 /	1				
KS2514	SPRING PIN	∮2.5-14L	2	WV0901	MAIN PISTON		1				
KS3014	SPRING PIN	∮3-14L	1	WV1001	BUMPER		1	55		0	
KS3020	SPRING PIN	∮3-20L	1	WV1502	UPPER RAIL		1				
OP005A	O-RING	P5	1	WV1601	PUSHER		1				
OP038H	O-RING	37.7×3.5	1	WV1701	SEAT		1				
OS010A	O-RING	S-10	2	WV1801	SPRING		1		7		
QD0101	SIDE PLATE(L.H.)		1	WV1901	HANDLE CUSHION		1				
QD0201	MAGAZINE SEAT		1	WV2001	NAIL STOP		1				
QD0301	MOVABLE PLATE		1	WV2401	ARM RIGHT LINK		1				

 \star \gtrsim If you need to order parts, please mark both Parts No. and Description. \precsim

We: SUMAKE INDUSTRIAL CO., LTD.
4F, No. 351, Yangguang St., Neihu District, Taipei City, Taiwan
declars in cole responsibility that the equipment
Equipment : Air D-Ring Gun
Model/ Serial No. : ATR30S
to which this declaration applies, complies with these normative documents:
Machinery Directive: 2006/42/EC
and conforms to the following EN standard,
EN ISO 12100: 2010 EN ISO 11148-13:2018
EN 130 11140-13.2010
Name and Signature/Position Date and Place

(111)

Mike Su – Managing Director

Taipei, Taiwan

2020/12/9

ATR30S-D-2212A-AC