SUMAKE PNEUMATIC TOOLS



Air C-Ring Gun SC742

SUMAKE INDUSTRIAL CO., LTD 4F,NO.351,Yangguang St.,Neihu District TAIPEI, TAIWAN, ZIP:114-91



SC742-S-1404A-AC

 ϵ

TOOL SPECIFICATIONS

MODEL OF TOOL TOOL LENGTH TOOL HEIGHT TOOL WIDTH WEIGHT (WITHOUT FASTENERS) AIR INLET	
COMPRESSED AIR : Maximum permissible operating pressure Recommended operating pressure range AIR CONSUMPTION	
Noise dB(A) :	
A-weighted sound pressure level LpA	82.31 dB(A)
A-weighted sound power level LwA	95.31 dB(A)
Measurement uncertainty: 3dB	
Vibration (m/s ²):	
Hand-arm vibration value	3.58 m/s ²
Measurement uncertainty: 1.5 m/s ²	

Warning:

The vibration emission during actual use of the power tool can differ from the declared total value depending on the ways in which the tool is used; and of the need to identify safety measures to protect the operator that are based on an estimation of exposure in the actual conditions of use (taking account of all parts of the operation cycle such as the times when the tool is switched off and when it is running idle in addition to the trigger time).

List of fasteners for SC742 :

Crown	Shank Height	Shank Dia.	MAGAZINE					
23.5 mm , 0.93 "	12 mm , 0.47 "	1.6 mm , 0.063 "	100 pcs					



Foreword:

This pneumatic C-ring tool is designed for using C rings. Its well balanced, ergonomic, comfort non-slip cushioned grip and heavy duty driving ensure C ring closure to different sizes and types of round shape. This C ring tool is best fitted in specialty applications for instance automotive, bedding, furniture, fencing and wires.

Suitable applications:

Bedding, cage, lobster pot, wire and wire like applications, automotive seating cover, upholstery foam secured to frame, attaching labels, training plant, cords, bag closure, cargo nets, small rope and many more

Caution:

C-ring tools are ideal for applications where needs tying, fastening and tightening. Not suitable for stapling or nailing into concrete, masonry bricks or steel. Do not fire if nails are jammed, as this will cause damage to the C-ring tool.

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury

Indicates an potentially hazardous situation which, if not avoided, will result in death or serious injury.

\Lambda NOTE

Alerts the operator to useful information.

SAFETY INSTRUCTIONS

- 1. Read this manual and understand all safety instructions before operation the tool. If you have any questions, please contact our authorized representatives.
- 2. Only those fasteners listed in the operating instructions may be used in the fastener driving tools.
- 3. Only the main energy and the lubricants listed in the operating instructions may be used.
- 4. Fastener driving tools equipped with contact actuation or continuous contact actuation, marked with the symbol " Do not use on scaffoldings, ladders", shall not be used for specific application for example:
- when changing one driving location to another involves the use of scaffoldings, stairs, ladders, or ladder alike constructions, e.g. roof laths,

-closing boxes or crates,

- -fitting transportation safety systems e.g. on vehicles and wagons.
- 5. For the maintenance of fastener driving tools, only spare parts specified by the manufac-

turer or his authorized representative shall be used.

- 6. Repairs shall carried out by agents authorized by the manufacturer or by other specialists, having due regard to the information given in the operating instruction.
- 7. Stands for mounting the fastener driving tools to a support for example a work table shall be designed and constructed by the stand manufacturer in such a way that the fastener driving tool can be safely fixed for the intended use, thus for example avoiding damage, distortion or displacement.
- 8. Fastener driving tools operated by compressed air shall only be connected to compressed air lines where the maximum allowable pressure cannot be exceed by a factor of more than 10%, which can for example be achieved by a pressure reduction valve which includes a downstream safety valve.
- 9. When using fastener driving tools operated by compressed air, particular attention must be paid to avoid exceeding the maximum allowable pressure.
- 10. When using fastener driving tools operated by compressed air should only be operated at the lowest pressure required for the work process at hand, in order to prevent unnecessarily high noise levels, increased wear and resulting failures.
- 11. Hazards caused by fire and explosion when using oxygen or combustible gases for operating compressed air operated fastener driving tools.
- 12. Carry the fastener driving tool at workpiece using only the handgrip, and never with the trigger actuated. Never carry the tool by the hose or pull the hose to move the tool.



13. Disconnect the tool from air supply before cleaning jams, servicing, adjusting, and during non-operation.



14. Wear eye protection.



15. Do not use a check valve or any other fitting which allows air to remain in the tool



16. Do not place your hand or any part of your body in the fastener discharge area of the tool when connecting or disconnecting air supply.

17. Never point tool at yourself or at any other person.

AIR SUPPLY AND CONNECTION

▲ NOTE



· Many air tool users find it convenient to use oiler to help provide oil circulation through tool and increase the efficiency and useful life of the tool. Check oil level in the oiler daily.

 Many air tool user find it convenient to use a filter to remove liquid and impurities which can rust or wear internal parts of the tool. A filter also increase the efficiency and useful of the tool. The filter must be checked on a daily basis and if necessary drained. For better performance, install a 3/8" quick connector (1/4" NPT threads) with an inside diameter of .315" on your tool and a 3/8"

quick coupler on the air hose. The following illustration shows the correct mode of connection to the air supply system which will increase the efficiency and useful life of the tool.



LUBRICATION AND MAINTENANCE

NOTE

· Disconnect the air supply from the tool before lubricating.



- · Your tool requires lubrication before you use it for the first time.



· Wipe off excessive oil at the exhaust. Excessive oil will damage O-rings of tool. If in-line oiler is used, manual lubrication through the air inlet is not required on a daily basis.



• Turn the tool so the inlet is facing up and put one drop of high speed spindle oil, UNOCAL RX22, or 3-IN-1 oil into air inlet. Never use detergent oil or additives. Operate the tool briefly after adding oil



LOADING THE TOOL



· Do not place your hand or any part of your body in the fastener discharge area of the tool when connecting or disconnecting air supply.

· Never point any operational fastener driving tool at

MARNING



yourself or at any other person.



1 Disconnect air hose



2. Depress the magazine latch. Pull back on the magazine cover



3. Insert a stick of fasteners into the magazine. Make sure the pointed ends of the fasteners are loaded with the points downward. Also make sure fasteners are not dirty or damaged.



4. Push the magazine cover forward until the latch catches

OPERATING THE TOOL



Protect your eyes and ears. Wear z87.1 safety glasses with side shields. Wear hearing protection. Employers and users are responsible for ensuring the user or anyone near the tool wear this safety protection.



1300 000

Fig.2

- are not legible 1. Add a few drops of UNOCAL RX22 or 3-in-1 oil into the air inlet.
 - (See Fig. 1)
- 2. Attach a high flow quick connect fitting to the tool. (See Fig. 2)

4. Connect the tool to an air compressor using a 3/8" I.D hose.

Make sure the hose has a rated working pressure exceeding 200 PSI (13.8bar) and a female quick coupler. (See Fig. 3)

5. Regulate the air pressure to obtain 70 PSI (4.8 bar) at the tool.

3. Empty the magazine.

(See Fig. 4)

200 PSI WP _____ ♂____3/8" I.D. Fig.3



- 6. Disconnect the air supply from the tool.
 - 7. Load fasteners into your tool following the instructions in this manual. (See Fig. 5)
- 8. Reconnect the air supply to the tool.
- 9. Test for proper fastener penetration by driving nails into a sample piece of wood. If the fasteners do not achieve the desired penetration, adjust the air pressure to a higher setting until the desired penetration is achieved. Do not exceed 110 PSI (7.6 bar) at the tool. (See Fig. 6)







Never use gasoline or other flammable liquids to clean the tool. Vapors in the tool will ignite by a spark and cause the tool to explode and result in death or serious personal injury.

NOTE



Solvents used to clean the nose of the tool and contacr safety trip mechanism may soften the tar on the shingles and cause the buildup to be accelerated. Make sure to dry the tool thoroughly after cleaning and before operating the tool again.



1. Disconnect the air supply from the tool.



2. Remove tar buildup with kerosene #2 fuel oil or diesel fuel. Do not allow solvent to get into the cylinder or damage may occur. Dry off the tool completely before use.

"C" RING

can be seen in the preceding pages, visibly defective rings can be the cause of many ring forming troubles.

Flared Rings In A Strip



Rings Skewed On A Strip



BURRS FROM FORMING

Unsymmetrical

CLEARING A JAM FROM THE TOOL

Disconnect the tool from air compressor before adjusting, clearing jams, servicing, relocating and during non-operation.

- 1. Fastener jammed in fastener discharge area: · Disconnect tool from air hose.
- · Grab jammed fastener with pliers and remove.
- 2. Fastener jam inside magazine:
- · Disconnect air tool from air hose
- · Pull back on fastener pusher until locked.
- · Removed jammed fastener.
- · Release fastener pusher.

CLEANING THE TOOL







Hogringers are designed to operate with rings manufactured within standard tolerances. As









Check and replace any damaged or worn components on the tool. The safety warning labels on the tool must also be replaced if they

CORRECTING AIR LEAKS IN TOOLS

The source of air leakage is most commonly the throttle assembly or the liner housing seal. The procedure will assist the repairman is solving this problem quickly

The throttle is basically a pair of two-way valve that divert air in front of, or behind the piston to crimp a ring or load a ring in the jaws respectively. The figures below show the air routings for both positions.

Follow the disassembly instructions and replace all o-ring.

Verify that the trigger contact area is not worn. If worn, the valve will not cycle completely(replace the trigger)

Follow the re-assemble and adjustment instructions.

If the air leak persists, inspect the piston, piston o-ring, piston rod bushing and bushing oring. Replace if any appear worn.

If the tool still leaks air, the throttle valve bushing or piston liner may be leaking. Have tool serviced at your dealers.

To Disassemble:

- 1. Remove front sub-assembly from housing
- 2. Remove air deflector parts (#1, #2).
- 3. Loosen set screws (#15)on both ends.
- 4. Remove rear valve seat(#3)
- 5. Remove throttle spring and locator parts(#4,#5)
- 6. Remove front valve seat(#13) and throttle stem(#14) using a wrench.
- Using two 3mm Allen wrenches, unscrew throttle valve screws(#6) to remove valve unit. Hint: Hold housing so the the valve is vertical to help prevent loosing parts.
 One valve screw will remain with other valve parts on spacer(#12), and can be
- disassembled after removal from housing.

To Re-assemble

- Assemble one side of the o-ring support assemble (#6, #8, #9, #10, #11, #10 and #9) on spacer(#12). The chamfer on both washer(#8) should be installed, with chamfer side against cap screw head(#7)
- Hold housing vertically and install o-ring support assembly with spacer into bushing from the top.
- Holding cap screw with an Allen wrench, bring second o-ring support assemble(mounted on screw(#7)) in front opposite side and complete valve assembly. The valve should have free motiom od travel of about (2.5mm).
- 4. Insert valve spring locator and spring(#5 and #4) into the socket head cap screw(#7) int the rear of the valve port.
- 5. Screw rear seat with lubricated o-ring (#3 and #7) into rear of the valve port.
- Insert throttle stem(#14) into front valve seat(#13) so that the rounded end is out and slowly screw front valve seat with lubricated o-ring(#7) into front of the valve port.
- Leave trigger guard loose for adjusting the valve. See throttle valve adjustment procedure for proper valve adjustment instructions.

Throttle valve adjustment instruction

Follow these steps after complete tool assembly in order to minimize the time and effort required for optimum throttle valve adjustment.

- Using the valve stem(#14), slowly screw in the front valve seat(#13) until it bottom, then back it out 1-1/2 turns.
- 2. Do the same with the rear valve seat(#3)
- Attach an air line and fully depress the trigger. Air Should Leak OUT OF THE REAR VALVE SEAT. While depressing the trigger, slowly turn in the rear valve seat(#3) until the air stops leaking.
- 4. Release the trigger. AIR SHOULD LEAK OUT OF THE HANDLE. Place a 5mm wrench on the trigger valve stem air stops leaking from the handle.
- Gently depress the trigger. Air should flow evenly from the rear exhaust to the handle exhaust.
- 6. The valve should now be adjusted-test the tool.
- 7. Tighten the front and rear valve seat locking screw(#15) and re-test the tool.



ADVANCING RING

TROUBLESHOOTING

Stop using the tool immediately if any of the following problems occur. Serious personal injury could. Any repairs or replacements must be done by a qualified person or an authorized service center only.

	PROBLEM	CAUSE	SOLUTION		
	Inside diameter of ring too large after clinching	Latch wom Wrong latch used(too short) Latch spring broken Wrong piston rod(too short) Low power 1.air pressure set too low	Replace latch Verify and replace latch Replace latch spring Verify and replace piston rod Verify pressure 1 check air pressure setting (operator manual)		
		2.air leaks in supply hose 3.air leak in tool 4. Throttle valve not adjusted properly Wrong jaws used Wron Jaws(helix, cam surface, bolt holes, iaw bushinns	2. Replace air supply hose 3.See Throttle valve adjustment instruction 4.Adjust throttle valve valve properly Verify and replace jaws Replace jaws Replace rollers		
1		Worn rollers Wrong rollers- 1.wire too hard 2.rough surface 3.cut-off burrs	Verify and replace rollers A further ring test to be done please return sample of rings to your dealers.		
	Inside diameter of ring too small after dinching	Wrong jaws Jaw stops worn or polished off	Verify and replace jaws Replace jaws		
/	Ring point not entering opposite jaw	Tip of jaw broken off Mismatched jaws- 1.jaws should be replaced only in pairs Defective rings- 1.Points not equal 2.Ring not symmetrical 3.Cut-off burrs Helix in jaw 'A' worn so that it dose not properly guide the ring point into the rotating helix in jaw 'B' as shown	Replace jaws Verify and replace jaws A further ring test to be done please return sample of rings to your dealers. Correct by chamfering the tip of helix that the ring is entering as shown in		
	Figure B	Rings only curling in one jaw	the shaded area in figure "C" Replace jaws		
	View A-A Figure C	Λ			
	Ring tear drops instead of forming	Laton wom Wrong latch(loo short) Latoh spring bent or broken(spring must hold latch tightly against end of side plate and against jaws) Feeder blade- 1.wrong feeder blade(loo short) 2.Modified by custome 3.worn(rounded on leading edge) Wrong or wom side plate Defective ring- 1.Burrs 2.Twisted	Neplace latch Verify and replace latch Replace latch spring Feeder blade 1.Verify and replace 2.Do not modify parts 3.replace feeder blade Replace side plate A further ring test to be done please		
	Rings jam	3.Not symmetrical Magazine- 1.Damaged or bent 2.Too many shims (the shim which ring passes through magazine edge is too big, ring out of control) 3.Too few shims (the shim which ring passes through magazine edge is too small, ring can not pass) 4.Worn magazine edge. 5. Frequent jamming can cause the magazine edge bent and increase the magazine width. 6.Loose or lost rear magazine mounting screw(magazine is not supported properly) Pusher spring loose Feeder blade- 1.worn(holes, length, thickness, leading edge) 2.broken 3.bent Ring groove in Jaw worn(see figure "D" Defective rings- 1.Burrs 2. Irings skewed on stick 3.Ring sout of line on stick 4.Ring wisded 5.Ring not symmetrical 6.Ring formed to size 7.Ring stip flare at the ends Wrong wire gauge for model of tool	return sample of rings to your dealers. Magazine		
	Rings don't feed down magazine	Pusher spring- 1.spring too loose 2.spring troken Damaged or bent magazine Defective rings- 1.undersized(tight on magazine) 2.burrs 3.ings twisted 4.rings skewed on stick 5.rings out of the on stick 6.ring strip flares at the ends	Pusher spring- 1. Adjust pusher spring 2. Replace pusher spring Replace magazine A further ring lest to be done please return sample of rings to your dealers.		
	Ring spitting	Air pressure too high Pusher spring loose Magazine 1.Damaged or bent 2.Too many shims (the shim which ring passes through magazine edge is too big, ring out of control) 3.Too few shims (the shim which ring passes through magazine edge is too small, ring can not pass) 4.Worn magazine edge. Worn Jaws(replace only in sets) Defective ring- 1.Burr on outside curve of ring	Verify proper air pressure Adjust pusher spring Magazine- 1. Replace magazine 2. Replace magazine 3. Replace magazine 4. Replace magazine Replace jaws Adjust jaws A further ring test to be done please		
	Snapping noise as ring is being fed from magazine	3.Rings out of line on stick 4.Rings not symmetrical 5.Wrong wire gauge for model of tool 6.Rings twisted opposite to jaw helix 7.Ring strip flares at the ends Too few shims under magazine 1.Too few shims (the shim which ring passes through magazine edge is too small, ring can not pass) Rings of wrong wire gauge used in tool-too large	Replace magazine Verify rings and use correct rings for the given tool		

SC742 AIR C-RING GUN



Part_No	Description	Spec	Q'ty	Part_No	Description	Spec	Q'ty	Part_No	Description	Spec	Q'ty
AA3401	PUSHER SPRING		1	WS0401	EXHAUST CAP		1	WS2401	TRIGGER		1
CC1901	BUSHING	. 7	1	WS0501	O-RING SEAT		2	WS2501	GUARD TRIGGER		1
CC2601	PIN		1	WS0601	O-RING CAP		4	▲ WS2601	LATCH		1
JA0901	NUT		2	WS0701	SPACER		2	WS2701	PLATE		1
KD0406	SCREW	#4×6 TP	1	WS0801	BODY		1	WS2801	MAGAZINE SEAT		1
KK0505	HEX.SOC.SET SCREW	M5×0.8 - 5L	2	WS0901	MAIN PISTON		1	WS2901	SPRING		1
KM0410	HEX.SOC.HD.BOLT	M4×0.7 - 10L	2	WS1001	ROLLER		4	WS3001	SEAT		1
KM0525	HEX.SOC.HD.BOLT	M5×0.8 - 25L	2	WS1102	ROD PISTON		1	WS3101	ROLLER		2
KM0635D	HEX.SOC.HD.BOLT	M6×1.0 - 35L	2	WS1201	SUPPORT		1	WS3201	ROLLER		1
KP5012	PARALLEL PIN	∮5×12L	2	WS1201W	TRIGGER VALVE GUIDE ASSY.		1	WS3301	PUSHER		1
KR0506	BUTTON HD.BOLT	M5×0.8 - 06L	2	WS1202W	TRIGGER VALVE GUIDE ASSY.	\bigcirc	1	WS3401	SUPPORT		1
KR0508	BUTTON HD.BOLT	M5×0.8 - 08L	1	WS1301	CYLINDER CAP	\sim	1	WS3501	STOPPER		1
KR0510	BUTTON HD.BOLT	M5×0.8 - 10L	1	WS1401	TRIGGER VALVE STEM		1	WS4201	ROLLER ANCHOR		1
KR0525	BUTTON HD.BOLT	M5×0.8 - 25L	5	WS1501	BUMPER		1	WS5601	SPRING		1
KS3018	SPRING PIN	∮3-18L	3	WS1601	SPRING SEAT	///	1	YL0508	LOCK NUT	M5×0.8	4
OA011H	O-RING	7.65×1.78	5	WS1701	COMPRESSION SPRING		1				
OA014A	O-RING	ARP568-014	2	WS1803	PAWL LOWER		1				
OA219H	O-RING	32.92×3.53	1	WS1903	PAWL UPPER		1				
WS0101	TRIGGER VALVE GUIDE		1	WS2002	DRIVER		1				
WS0201	TRIGGER VALVE GUIDE	1	1	WS2101	САР		2			1	1
WS0301	TRIGGER VALVE SEAT	1	1	WS2201	САР		1			1	1
WS0303W	DRIVER ASSY.	1	1	WS2301	SIDE PLATE		2			1	1

 \star \gtrsim If you need to order parts, please mark both Parts No. and Description. \precsim

EC DECLARATION OF CONFORMITY

We: SUMAKE INDUSTRIAL CO., LTD.

CE

4F, No. 351, Yangguang St., Neihu District, Taipei City, Taiwan

declare in sole responsibility that the equipment

Equipment: AIR C-RING GUN

Model/ Serial No. : SC742

to which this declaration applies, complies with these normative documents:

Machinery Directive: 2006/42/EC

and conforms to the following EN standard,

• EN ISO 12100: 2010

EN ISO 11148-13:2018

Name and Signature/Position

Mike Su – Managing Director

Date and Place

2020/12/9

Taipei, Taiwan

SC742-D-2304A-AC