

SUMAKE[®]

Professional & Industrial

INSTRUCTION MANUAL

ITEM NO.: SF30F series

AUTOMATIC SCREW SUPPLIER



SF30F series-I-2312A-YM

Table of Contents

I.	About SF30F	
1.	Features.....	P3
2.	Specifications.....	P3
II.	Installment	
1.	Preparation.....	P4
2.	Tryout.....	P6
3.	Normal Operation.....	P7
4.	After Operation.....	P7
5.	Maintenance.....	P8
III.	Adjustment and Replacement	
1.	Air Pressure Adjustment.....	P9
2.	Screw Deliver time Adjustment.....	P9
3.	Screw Deliver Air Volume Adjustment.....	P10


I. About SF30F

1. Features

1. Designed for speed, stability, and convenience.
2. Improving screw driving speed and work efficiency by integrating pneumatic/ electrical screwdriver, high-tech automatic feeder, and high precision jaw.
3. The jaw is customized by particular screw and working environment to provide a stable operation.
4. Standard pneumatic screwdriver; optional models by customer also available.

2. Specification

Model	L / W / H	Weight	Voltage	Air Pressure
SF30F	44 / 25 / 39 (cm)	24 kg	AC 220 V	5 ~ 6 kg / cm ²







II. Installment

1. Preparation


1. Connect the screw delivery hose, air hose and signal cable to the feeder unit

- Take a balance of the driver unit for easier fastening. While taking balance, make sure that the signal cable and air hose do not contact with hook or balancer wire. Care should be taken to prevent excessive bending or twisting of hoses and cables, since this can cause damage or disconnection.
- Connect the screw delivery hose between the feeder and the driver as soon as possible. Make sure that it is not excessively bent or twisted after installation.

Delivery hose	Signal Cable
	
Cor	Incorrect Delivery hose installment
	

2. Connect feeder unit to compressed air source with an air hose supplied.

Air pressure for the feeder unit is 5-6 kg/cm².



2. Since this unit has no provisions for adjusting air pressure, pressure must be controlled at the source.

(PULL UP FIRST, AND ROTATE)




4. Screw delivery timer check.

Check screw delivery timer setting on the front of the feeder unit.



Standard operation setting is between 0 to 1.

5. Connect power cord to a single-phase AC-220 wall outlet.




2. *Tryout*

1. Open the hopper and cover and load hopper with a small quantity of screw.

Load Screws	Max Volume
	

2. Turn power switch on.

The power and motor pilot lamps will light, the feeding track will start reciprocating and screw will be fed into the chute. Once the chute is filled, the rotary drum automatically stops and the motor pilot lamp will go off.





3. While holding the driver unit, telescope the Y-pipe manually.

One cycle will send a signal to the feeder from the driver unit and the escapement will release one screw from the chute for delivery to the driver's tip by compressed air. First cycle has a 3~5 seconds delay of feeding.

-  Never point the driver tip toward a person since a screw might shot out accidentally, causing possible injury.

3. Normal Operation

1. After all preparatory steps have been completed, load screw into the hopper.
2. Turn power switch on.

1. Load Screws	2. Turn Power Switch
	

4. After Operation

1. Lubrication

Loosen the needle valve of the oiler while idling the driver. After confirming oil flow of 3 to 5 drops through the window, retighten the needle valve. Then, idle the driver unit alone for one or two minutes to allow oil to circulate.
2. Chute cleaning

With a brush, remove dust and metal fragments from sliding surface of chute. Remove any grease with a cloth soaked in alcohol.

Be sure power switch is turned off. Do not scratch or bruise the chute-sliding surface during cleaning.
3. Power

Turn power switch off after completing operations.

5. Maintenance

1. Cleaning hopper interior

Clean the hopper interior once a week. Remove any remaining screw and dust. If the interior is extremely dirty, wipe thoroughly with a clean

2. Draining water from filter Water accumulated in the filter should be drained by loosening the drain cock.


Draining water



III. Adjustment and Replacement

1. Air Pressure Adjustment

Air pressure supply to feeder unit must be within 5-6 kg /cm².



2. Screw Deliver time Adjustment

Screw delivery time is the time for the screw to pass through the screw delivery hose to the driver jaw. Adjust screw delivery time by setting the timer on front of the feeder. 0 on the dial indicates the shortest time (approx. 0.1 sec.) and 10 indicates the maximum time (approx. 2 sec.) Standard operation setting is 1 to 2.

If the time is too short, screw may sometimes not be delivered.

The screw delivery time will vary depending upon the type of screw and length of screw delivery hose.

Determine the most appropriate level by trial-and-error. Confirm that screws are delivered to the driver jaw.



3. *Screw Deliver air Volume Adjustment*

If satisfactory screw delivery cannot be obtained by time adjustments, the screw delivery air volume must be reset by turning the switch rod adjustment screw on right of the feeder escapement. The volume of air supplied to screw delivery hose increases when the lock nut is loosened and the switch rod adjustment screw is turned *counterclockwise*. This operation also increases screw delivery speed. Turn screw *clockwise* to decrease air volume and slow delivery.

After adjustment, tighten the nut securely.

Screw delivery air volume adjustment



REMEMBER:

The numbers 1, 2, 3 on the housing do not indicate actual torque. They simply indicate whether the tool is towards the high, low or middle of its range.

EU Declaration of Conformity (DOC)

We: **SUMAKE INDUSTRIAL CO., LTD.**

4F, No. 351, Yangguang St., Neihu District, Taipei City, Taiwan

declare in sole responsibility that the equipment

Equipment : **AUTOMATIC SCREW FEEDER**

Model/ Serial No. : **SNF-A1, SNF-A2, SNF-A3, SNF-A4, SNF-A8, SNF-A9,
SNF-A10, SNF-A11, SNF-A12, SNF-A13, SF40TH, SF30A,
SF30M, SF30T, SF40A, SF40T, SF501, SF501T, SF502,
SF502T, SAF-100S, SAF-100G, SAF-100L, SAF-100R, SDA,
SF-SERIES, SF20, SF20M, SF20T**

The object of the declaration described above is in conformity with the relevant union harmonization legislation:

- Machinery Directive 2006/42/EC
- Low Voltage Directive: 2014/35/EU
- RoHS 2011/65/EU

The following harmonised standards and technical specifications have been applied:

- EN ISO 12100:2010
- EN ISO 13849-1:2023
- EN ISO 13850:2015
- EN ISO 13857:2019
- EN ISO 4414:2010
- EN 60204-1:2018

Name and Signature/Position



Mike Su – Managing Director

Date and Place

2025/8/11

Taipei, Taiwan

NOTE

SUMAKE®

SUMAKE®