

OPERATION AND MAINTENANCE MANUAL

ITEM NO.: **EAA-WSCBSN-1**
WIRELESS SIGNAL I/O CONTROL DEVICE




I. Panel Function



Display Screen:

Boot Version: (Ver 1.xxx)

16X2 LCM Display Setting Function , EAA-WSCBSN-1 connected to EMS(W)-B14 series picture:



- S99-99-19: Display Sequence--(Program)-(Tool) ◦
- 03/05: Display Count Value
- C: Display Screwdriver Action Number of Turns
- OKALL: Display status (OK, NG, OKALL)

Up Key: Setting mode Up key switch function.

Down Key: Setting mode Down key switch function.


Left Key: Setting mode Left key switch function

Right Key: Setting mode Right key switch function


Esc Key: Press three seconds to enter/leave the setting mode.

↵Key: CONFIRM key


OK, NG, OKALL, start, Rev, Dis, POWER: Display status indicator.



1. OUTPUT: External output control , The OUTPUT pin define is customized. Please go to CTRL Setting [9]Ext Output for setting.
2. INTPU: External input control , The OUTPUT pin define is customized. Please go to CTRL Setting [8]Ext Input for setting.
3. PORT1 (RS232): Connect to DAS or wifi module.



1. Switch element: turn on or turn off the module power
2. USB port: Connect to the barcode reader.
3. MicroSD Card port: Used to store data.
4. Cable communication port: Used to online.



1. Micro USB port: Used to connect Micro harness.
2. RS232: Reserved port, no function for now.
3. USB port: Used to connect bluetooth module.
4. Power supply port: Used to supply power to module.

II. Status

It shows status of EAA-WSCBSN-1 connected to EMS(W)-B14 series. Press Up/Down to show current status #1~#5 of Program and Sequence:

- #1 Show status of Program:
 AT1.0: OKALL signal holding time
 n05: Screw count. F01: Impact Force.
 H10: Impact parameter. L00: Limit rotation number setup
u00: Ignore Rundown Friction.

```
A T 1 . 0      n 0 5      # 1
F 0 1      H 1 0      L 0 0      u 0 0
```

- #2 Show status of Program:
 c00:Pre-tighten thread. FWD/REV: CW/CCW.

```
c 0 0      F W D      # 2
```

- #3 Show status of Gate:
 Gate=Once (Hi): Status of Gate. [None/Once (Hi)/Twice/Once (Lo)]
 Ac=ON: Disable EMS(W)-B14 SERIES when batch completed [ON/OFF]
 Nc=ON: Disable EMS(W)-B14 SERIES when NG occurred. [ON/OFF]

```
G a t e = O n c e ( H i )      # 3
A c = O N      N c = O F F
```

- #4 Show current Sequence, Program, number of EMS(W)-B14 series and name of program:
 T01: Sequence – Program - Tool
 P99: Current program number.
 SCREW 001: name of program.

```
S 9 9 - P 9 9 - T 1 9      # 4
P 9 9 : S C R E W      0 0 1
```

- #5 Show connected EMS(W)-B14 series MAC number:
 T01: connected EMS(W)-B14 series number.
 168880111302: EMS(W)-B14 series MAC number.

```
T 0 1      B T      M A C :      # 5
1 6 8 8 8 0 1 1 1 3 0 2
```


III. Set Function Options and Operating Instructions

1. After switching on the power, to enter into the function menu, press the “Esc” key on the panel for 3 seconds, following which password input is required to enter the menu.




2. Open Bluetooth of EMS(W)-B14 series and connect EMS(W)-B14 series to EAA-WSCBSN-1.

3. After setting, press "ESC". It will show EMS(W)-B14 series connecting as below

T 0 1 C o n n e c t i n g . .
1 6 8 8 8 0 1 1 1 3 0 C

4. When the EMS(W)-B14 series does not run for over 30 mins, it will enter the sleep mode. Press trigger to activate.

CTRL Setting			
Name	Set Up Time and Value	Function Description	Default
[1] Query Tool	0-0~J-J xxxxxxxxxxxxxx	<p>(1). Search EMS(W)-B14 series list and find EMS(W)-B14 SERIES Bluetooth MAC number, it is able to choose EMS(W)-B14 series by order via [2] Tool Pair. For example: A-3 168880111302, “A” mean total 9 EMS(W)-B14 series, “3” mean the 3rd EMS(W)-B14 SERIES, “168880111302” mean MAC number. Press Up/Down to check, and confirm by Enter.</p> <p>(2). We suggest to connect EMS(W)-B14 series to EAA-WSCBSN-1 one by one. Follow first step to detect 2nd, 3rd. EAA-WSCBSN-1 is able to detect 19 EMS(W)-B14 series.</p> <p>(3). If user take Bluetooth dungle of EMS(W)-B14 series to EAA-WSCBSN-1, it will became Master. After user take Bluetooth dungle to EMS(W)-B14 series. It have to close EMS(W)-B14 series Bluetooth and open again. That Bluetooth dungle will become Slave and able to dected by EAA-WSCBSN-1 by Query Tool function.</p>	NA
[2] Tool Pair	T01~T19 MAC number of Tools	<p>(1). Press left/right to select EMS(W)-B14 series (T01...T02...etc), and press enter to let MAC number blink. And then press up/down to select Tool Pair 1~19 and press enter to save.</p> <p>[2] T o o l P a i r 2 T 0 1 1 6 8 8 8 0 1 1 1 3 2 2</p> <p>(2). While MAC number blink, Tool Pair number become 0, it means EMS(W)-B14 series match MAC number completed.</p>	NA

		<p>[2] Tool Pair 0 T 0 1 1 6 8 8 8 0 1 1 1 3 2 2</p> <p>(3). While MAC number blink, select Tool Pair 20 and MAC number is 000000000000. Press enter the Matched EMS(W)-B14 series and its MAC number will be cleared.</p> <p>[2] Tool Pair 20 T 0 1 0 0 0 0 0 0 0 0 0 0 0 0</p>	
[3] SEQ Numbers	S 00~99 E 00~99(≥S) S 00=OFF(S01)	The first (S xx) and the last (E xx) sequence. For example S01→E05 means EAA-WSCBSN-1 will let EMS(W)-B14 series run a sequence from program 1 to program 5; If select S00, it will set S Off and only run one program.	S OFF = S 01
[4] Sequence	SEQ01 P01 T01 P:	(1).Setting sequence parameter, Program as (Program), EMS(W)-B14 series as (Tool), P: program name (SCREW Setting [1]Program/Name) (2).As program set P00, job sequence will pass this program to next.	SEQ01 P01 T01 P:
[5] Gate Mode	None Once(Hi) Twice Once(Lo)	<p>Gate function:</p> <p>(1).None: Function off.</p> <p>(2).Once(Hi): Workpiece in position (Short signal.) high is active and low is deactivate.</p>  <p>(3).Twice: Workpiece in/out position (Open signal) Low is active and high deactivate.</p>  <p>(4).Once(Lo): Workpiece in position (Open signal.) Low is active and high deactivate.</p> 	None
[6] OKALL Signal	Each SEQ All SEQ Done	<p>OKALL signal output method</p> <p>Each SEQ: Output OKALL signal after each sequence completed.</p> <p>All SEQ Done: Output OKALL signal after all sequences completed.</p>	Each SEQ
[7] BC1 S01-01-01	BC1~9 S01~S99 (C03~C05)	<p>Barcode learning function.</p> <p>(1).BC1~9: Barcode program, press left/right to select barcode program.</p> <p>(2).S01~S99(C03~C05) : S is sequence number, C is control code. Press enter to setting and select S or C. S Sequence: It is only able to use on setting [3]SEQ Numbers is S OFF=S 01. Adjust S01~S99, program and EMS(W)-B14 series will bring [4]Sequence setting. C control code:</p>	BC-1 S01-01-01

		<p>C03:Confirm, deactivate NS and AS. C04:Clear, clear current screw count. C05:Reset SEQ, reset current sequence.</p> <p>(3).On setting (blink) scan barcode, barcode will show on second line. Left/right to move on barcode and up/down to change barcode to *. For example, it will show barcode as BC1*S01-01-01.</p>	
--	--	--	--

<p>[8] Ext Input <- I-1 -></p>	<p>I-1~I-5 View (Read Only) Pin 1,3,5,7,9, 11,13 Enter to Set Goto SEQ-01~99 Disable Confirm Clear Gate Reset SEQ Select Enter Select SEQbit0~4</p>	<p>Output signal pin define setting. There are 4 section. Press Enter to go into 1 section and press ESC to back.</p> <p>(1).Select section: Left/right could select I-1~I-5 5 sets of signal number.</p> <pre>[8] E x t I n p u t < - I - 1 - ></pre> <p>(2).View section: Left/right to view each pin define. I-1 only for view not allow to edit. I-2~I-5 is able to edit.</p> <pre>[8 .] I - 1 V i e w - > (R e a d O n l y)</pre> <p>(3).edit section: In edit section, press enter is able to edit I-2~I-5.</p> <pre>[8 .] I - 2 V i e w - > E n t e r t o S e t <-J</pre> <p>In edit section, press up/down to select each pin define. After select each pin define, press enter to confirm. Until all pin is setting and back to view section, the setting is saved.</p> <pre>[8 .] I - 2 P i n 1 - > . S e l e c t S E Q b i t 0</pre> <p>(4).Number section: On Goto SEQ-xx press enter to let number blink and press up/down to select sequence number. This function only active on [3]SEQ Numbers is S OFF=S 01.</p> <pre>[8 .] I - 2 P i n 3 - > . G o t o S E Q - 9 9</pre> <p>(5).Select section: Press left/right to select <-I-1->~<-I-5-> signal, and press enter to go to edit section. If press ESC quit, the signal number will not be edited. Only one pin is able to be signal input.</p> <p>(6).Input signals function definition: Goto SEQ-01~99(change sequence), Disable(Disable EMS(W)-B14 series), Confirm(deactivate NS & AS), Clear(clear screw count), Gate(gate), Reset SEQ(Reset sequence), Select Enter(binary sequence number enter),</p>	<p><- I-1 -></p>
--	---	---	------------------------

		<p>SEQbit0~4(binary sequence number)</p> <p>(7).Gate function: In order to set Gate function Input signal must set Gate. [5]Gate Mode function is able to set.</p> <p>(8).Reset SEQ (Reset sequence) is in [3]SEQ Numbers as S OFF=S 01. It will return to the first sequence. As [3]SEQ Numbers is multi sequence, it will return to the first sequence.</p>	
--	--	---	--

		<p>(9).SEQbit0~4: SEQbit0 is LSB, bit4 is MSB, there is 31 unit for sequence S01~S31. For example Pin as setting as below picture:</p> <pre> Pin 1 SEQbit0 High 0 (LSB) Pin 3 SEQbit1 Low 1 Pin 5 SEQbit2 High 0 Pin 11 SEQbit3 Low 1 (MSB) </pre> <p>Set Pin3 as select enter, while signals show as above, it will switch to S10 sequence (binary 1010 is equal 10.)</p>	
<p>[9] Ext Output <- O-1 -></p>	<p>O-1~O-5 View (Read Only) Pin 1,3,5,7,9, 11 Enter to Set Start(Motor) Reverse(Motor)OK NG OKALL Disable Start(Trigger) SelBit0 SelBit1 SelBit2 SelBit3 SelBit4</p>	<p>Output signal pin define. There are 3 section. Press Enter to enter section, press ESC to back.</p> <p>(1). Selection section: Left/right to select O-1~O-5 five signal numbers.</p> <pre> [9] Ext Output < - 0 - 1 - > </pre> <p>(2). View section: Left/right to view each Pin define. O-1 is view only, not able to edit. O-2~O-5 is able to edit on edit section.</p> <pre> [9 .] 0 - 1 View - > (Read Only) </pre> <p>(3). Edit section: O-2~O-5. It is able to enter and edit each Pin.</p> <pre> [9 .] 0 - 2 View - > Enter to Set < J </pre> <p>In edit section, press up/down to select pin define and press enter to confirm. Until each pin define is set and back to view section, all setting is save.</p> <pre> [9 .] 0 - 2 Pin 1 - > . Start(Motor) </pre> <p>(4).Select section: Press left/right to select signal number <-O-1->~<-O-5->, it has to press Enter to enter Edit section. If press ESC to quit, signal number <-O-1->~<-O-5->will not change. It is only able to set one output signal pin at time.</p>	<p><- O-1 -></p>

		(5).Output signal pin define: Start(Motor)(EMS(W)-B14 series motor start) 、 Reverse(Motor)(EMS(W)-B14 series motor reverse start) 、 OK(tightening ok) 、NG(tightening NG) 、OKALL(All screws tightening ok) 、 Disable(EMS(W)-B14 series disable) 、 Start(Trigger)(EMS(W)-B14 series trigger on) 、 SelBit0~4(SEQBit0~4 of [8]Ext Input sequence change)	
[10]Device ID 001	001~250	Controller ID.	001

[11] Ext SEQ Ctrl	OFF	No use.	OFF
[12] Operator Standard	Standard	No use.	Standard
[13] Password 0000	0000~9999	Password to enter setting.	0000
[14] Default Val OFF	OFF Only Ctrl? Only Eth? Both?	Factory default setting. It is able to select Controller or LAN module, or Both.	OFF
[15] Data Port RS232	RS232 Ethernet RS232(Ack) Ethernet(Ack)	Select data transfer mode. Ack mode is data output, if does not receive CMD reply, it will re-send.	RS232
[16] System Date 2021/xx/xx	2020/01/01 2099/12/31	Date setting. (Store by CR2032 button battery)	2020/01/01
[17] System Time xx:xx:xx	00:00:00 23:59:59	Time setting. (Store by CR2032 button battery)	00:00:00
[18] Product No.	xxxxxxxxxxxxxxxxxx	Serial number.	NA
[19] Screw BT MAC 000000000000	xxxxxxxxxxxxxx	The last connected Bluetooth MAC number of EMS(W)-B14 series.	000000000000
[20] Screw FW Ver MB:0.00 CB:0.00	MB:1.07 CB:1.06	The last connected Version of EMS(W)-B14 series	MB:0.00 CB:0.00
[21] Ctrl BT MAC xxxxxxxxxxxxxx	xxxxxxxxxxxxxx	Bluetooth MAC of controller.	000000000000
[22] Ctrl FW Ver. Ver 1.001 SA000 ST: V1.01	Ver 1.001 SA000 ST: V1.01	1. Controller version Displayed regular and special edition firmware version of controller 2. Press Left / Right key to switch ST version	Ver 1.001 SA000 ST: V1.01
[23] SD Card 0.00 MB	0.00 MB	SD card Data Store. (Support 32GB and below.)	0.00 MB
[24] IP Address 192.168.0.7	192.168.0.7	Setting of [15]Data Port must set for Ethernet or Ethernet(ACK), it will IP address. Otherwise it will show “ Not Eth Port!”. Please reference IX. LAN port instruction for Ethernet connection.	192.168.0.7



SCREW Setting

Name	Set Up Time and Value	Function Description	Default
[1] Program/ Name	P01~P99	Select program/Program name: Press enter and number will blink. Press up/down to select program and press enter	P01

		(number stop blinking). Press down to enter [2]~[8] each program. Enter the selected program to setting.	
[2] OKALL Alarm	AT 0.0~AT 9.9	The duration of the OKALL Alarm signal after OK Batch is completed.	1.0
[3] Batch Count	n01~n99	Screw count number. When set n00, controller will not count screw count. In multi sequence, it will skip program set n00.	05
[4] Force	F01~F06	EMS(W)-B14 SERIES torque force setting. Adjust the impact force based on needs. EMS(W)-B1470(100) setting value is [F01]~[F06]; EMS(W)-B1450 setting value is [F01]~[F03] If controller set F04~F06, EMS(W)-B1450 will show F03.	F 01
[5] Impacts	H00~H99	The setting is [HoF] [H01]~[H99], and the number of Impacts is adjusted based on needs. [H00] is set unlimited impact until release trigger.	H10
[6] Limit	L00,L02~L99	The setting value is L00, L02~L99, during fasten operation, the EMS(W)-B14 series completes the fastening before reach request setting thread.	L00
[7] Ignore Rundown Friction	u00~u99	Ignore Rundown Friction: Even there is resistance between tightening, the EMS(W)-B14 series will keep hit until reach setting thread. The setting value is [u00]~[u99]. If set both ignore Rundown Friction and limit, the limit must larger then ignore Rundown Friction.	u00
[8] PreFastening	c 00 c 99	Pre-Fastening setting: (1).After fasten reach pre-fasten thread, EMS(W)-B14 series stop and count screw number. (2).If set Pre-Fastening, Limit and Ignore Rundown Friction, EMS(W)-B14 series will run Pre-Fastening.	c 00
[9] Rev Thred	rr=FWD rr=REV	FWD/REV setting FWD is Clockwise REV is Counter clockwise	rr=FWD
[*] OKALL Stop	Ac= OFF Ac= ON	Disable EMS(W)-B14 series when batch completed. Ctrl Setting 的[6]OKALL Signal Each SEQ/All SEQ Done of Ctrl are the same.	Ac =OFF
[*] NG Stop	nc= OFF nc= ON	Disable EMS(W)-B14 series when error occurred.	nc= OFF
[*] Sync Program	P01-05→P1-5 OFF/ 1T P99-99→P5-5 OFF/ 1T	(1).Select Program of controller and Sync to EMS(W)-B14 series. (2).Select 1~5 Program and press up/down to select “1T”then press enter. Pres “ESC” twice and connect EMS(W)-B14 series to Sync program to EMS(W)-B14 series. (3).Close the Bluetooth of EMS(W)-B14 series and close program switch. Save EMS(W)-B14 series setting and set EMS(W)-B14 series offline mode. (4).As EMS(W)-B14 series is offline mode, it will show Program 5 th and its screw count, please select the program which need. (5). Synchronization is unable to write FWD/REV to EMS(W)-B14 series offline mode. If request FWD/REV	P01-05→P1-5 OFF

		tightening, please go to setting of EMS(W)-B14 series SE3 for setting rrF/rn.	
[*] Sel Program	P o1 x2 x3 x4 x5 P o1 o2 o3 o4 o5	EMS(W)-B14 SERIES program cycle select. (1).Select Program cycle setting and sync to EMS(W)-B14 series. (2).For example: P x1 x2 o3 o4 x5. It shows offline EMS(W)-B14 series set Program 3 ~ Program 4 for a program cycle. (3).Sel Program must set before Sync Program. Referece as [*]Sync Program.	P o1 x2 x3 x4 x5
[*] Copy Program	P01→→→P02 N P98→→→P99 Y	It is able to select single Program setting and COPY to other, select “Y” and press enter.	

IV. Set Function Options and Operating Instructions

- 1) After switching on the power, to enter into the function menu, press the “Esc” key on the panel , following which password input is required and press  key to enter the menu
- 2) Press UP or DOWN key to select the setting page to enter; after that, press  key.
- 3) If data fails to flash, check the parameters; the flashing data can be increased/decreased.
- 4) When data isn’t flashing, the RIGHT/LEFT keys are disabled. When data is flashing, switch to the parameter to be adjusted.
- 5) Except [4] Sequence SEQ0x P0x T0x change data will save directly, other setting must press enter to save.
- 6) Press Esc to jump out from the setting page.

V. External Input Control Function Description

Connector No.	Definition	Function Description
CN 1	Goto SEQ-01	Default setting. When CN1 & CN2 short, controller go to SEQ-01. Only available CTRL Setting > [3]SEQ Numbers is S OFF=S 01.
CN 2	GND	Input power GND
CN 3	Goto SEQ-02	Default setting. When CN3 & CN4 short, controller go to SEQ-02. Only available CTRL Setting > [3]SEQ Numbers is S OFF=S 02.
CN 4	GND	Input power GND
CN 5	disable signal input Disable	1. When (CN5+CN6) is closed, the screwdriver disable rotation function is turn on. 2. When (CN5+CN6) is closed, the screwdriver disable rotation function is turn off.
CN 6	GND	Input power GND
CN 7	Confirm key input Confirm	1. When (CN7+CN8) is closed, confirm is selected. 2. When (CN7+CN8) is open, there is no input status.
CN 8	GND	Input power GND
CN 9	clear key input Clear	To clear the count value, the (CN9+CN10) closed circuit can enable the function.
CN 10	GND	Input power GND
CN 11	sensor switch GATE	1. When (CN11+CN12) is closed, article is detected. 2. When (CN11+CN12) is open, there is no article detected.
CN 12	GND	Input power GND
CN 13	Reset SEQ	Default setting. When CN13 & CN14 short, reset sequence.
CN 14	GND	Input power GND

VI. External Output Control Function Description

Connector No.	Definition	Function Description
CN 1	Start signal output START (Motor)	1. When (CN1+CN2) is closed, the screwdriver then start running. 2. When (CN1+CN2) is open, the screwdriver then stop running.
CN 2	COM	This pin refers to the START signal connection negative end
CN 3	Brake signal output Disable	1. When (CN3+CN4) is closed, Disable is displayed. 2. When (CN3+CN4) is open, there is no output status.
CN 4	COM	This pin refers to the BRAKE signal connection negative end
CN 5	Screwdriver reversed signal output Reverse (Motor)	1. When (CN5+CN6) is closed, the screwdriver then start reverse rotation. 2. When (CN5+CN6) is open, the screwdriver then stop reverse rotation.
CN 6	COM	This pin refers to the Reverse signal connection negative end
CN 7	After completion of fastening a screw OK	1. When (CN7+CN8) is closed, OK is displayed. 2. When (CN7+CN8) is open, there is no output status.
CN 8	COM	This pin refers to the OK signal connection negative end
CN 9	When error operation , NG is displayed	1. When (CN9+CN10) is closed, NG is displayed. 2. When (CN9+CN10) is open, there is no output status.
CN 10	COM	This pin refers to the NG signal connection negative end
CN 11	When the batch, work or job sequence completed, OKALL is displayed.	1. When (CN11+CN12) is closed, OKALL is displayed. 2. When (CN11+CN12) is open, there is no output status.
CN 12	COM	This pin refers to the OKALL signal connection negative end
CN 13	Vdc Positive DC voltage terminal	This pin is to provide the external positive voltage.
CN 14	GND Negative DC voltage terminal	This pin is to provide the external negative voltage.

※Remarks:

- INPUT** contact, if using non-isolating (wet contact) control, it needs to connect a 10K resistor in series on the line.
- When the automatic machine is installed, it is recommended to install the signal line on the machine and then connects to KL-EAA-WSCBSN-1.
When working with automatic control, pay attention to the above items to prevent equipment damage.
- INPUT/OUTPUT:** Please check CTRL Setting > [8]Ext Input & [9]Ext Output for the actual pin define.

VII. CONFIRM Mode

Code	Description	Remarks
C1	External GATE signal trigger once CONFIRM mode.	External GATE signal trigger once
C2	External GATE signal trigger twice CONFIRM mode.	External GATE signal trigger twice
C3	『OKALL Stop Ac= ON』, after batch complete, it will show 『C3』	Press Enter/ External CONFIRM
C4	『OKALL Stop Ac= ON』 & 『Gate Mode_Once(Lo)&Once(Hi)』, after batch complete, it will show 『C4』	External GATE Signal Trigger once + Enter/ External GATE Signal Trigger once + External CONFIRM
C5	『OKALL Stop Ac= ON』 & 『Gate Mode_Twice』after batch complete, it will show 『C5』	External GATE Signal Trigger twice + Enter/ External GATE Signal Trigger twice + External CONFIRM

VIII. BARCODE Operating Instructions

1. Hardware Configuration Description

Connect the Barcode Reader to the USB port specified on the diagram.



2. Operating Functions Description

2.1. CRTL Setting > [3]SEQ Numbers sets OFF, and set CRTL setting > [4]Sequence for each program and EMS(W)-B14 SERIES, and then it is able to use barcode scanner to switch different Sequence.

1. Use SUMAKE default barcode to switch Sequence (CMD.S01-CMD.S99)



CMD.S01



CMD.S99

Description:

1. Use CMD.S01~CMD.S99 barcode to switch sequence.
2. After switch Sequence, it will bring Program and EMS(W)-B14 SERIES by setting on CTRL Setting > [4]Sequence.

2.2. Barcode scanner could be confirm/enter for AS or NS

When set AS or NS, it disable EMS(W)-B14 series. It could use barcode Scanner to enable EMS(W)-B14 series. It is same as Confirm/Enter.

Use SUMAKE barcode format: CMD.C03 to release AS (okAll Stop) &NS(NG Stop) command



CMD.C03

Description:

As WSCNBS set AS or NS, it disable EMS(W)-B14 SERIES. Operator is able to use barcode scanner to scan CMD.C03 to enable EMS(W)-B14 series.

2.3 Barcode Scanner clear batch count.

During the operator tightening, it is able to use barcode scanner to clear batch count.

SUMAKE default barcode: CMD.C04 Clear Batch Count.




CMD.C04

2.4. Barcode Scanner reset sequence.

During the operator tightening, it is able to use barcode scanner to reset sequence


SUMAKE default barcode: CMD.C05 reset sequence.



CMD.C05

Description:

After reset sequence, due to CTRL Setting > [3]SEQ Numbers, it will to first sequence.






IX. LAN port instruction

(1) Set computer interface.


Connect LAN to EAA-WSCBSN-1 Ethernet port, another side connect to Computer Ethernet port.

Set computer IP to 192.168.0.X, due to WSCNSN deault IP is 192.168.0.7.

Step 1: Right Click  or  On computer and click “open network & internet settings”.




Step 2 : Status → change adaptor options → network connections, select Ethernet and right Click then select properties.



Step 3 :

- EAA-WSCBSN-1 and computer have connected to the same network (LAN). In EAA-WSCBSN-1 > CTRL Setting > [24]IP Address will show assign IP address. Enter this IP on browser in the computer will connect to EAA-WSCBSN-1.




Step 4 : Enter static IP and DNS (follow 192.168.0.xxx)then click OK.

【※】 If computer is static IP, please check its IP address is different as EAA-WSCBSN-1.


【※】 While change IP, please do not connect to internet.

(2)Log in website setting

Step 1:In EAA-WSCBSN-1 CTRL Setting > [15]Data Port set Ethernet or Ethernet(ACK). CTRL Setting > [24]IP Address will show default IP. And enter IP 192.168.0.7 in browser of computer. Account: admin // Password: admin Press Log-in.



Firmware Version : V3014



USR IOT

-IOT Experts-

Be Honest, Do Best!

Current Status	parameter	help
Local IP Config	Module Name: USR-K3	<ul style="list-style-type: none"> Run time: run time means the minutes since latest reboot TX/RX Count: TX/RX count give us a calculation of the total byte we have been received or send.
TTL1	Firmware Revision: 3014	
Web to Serial	Current IP Address: 192.168.0.7	
Misc Config	MAC Address: d8-b0-4c-c1-ff-2d	
Reboot	Run Time: 0day: 0hour: 3min:18	
	TX Count(ETH) : 0 bytes	
	RX Count(ETH) : 0 bytes	
	Conn Status(ETH)A: LISTEN	
	Conn Status(ETH)B: IDLE	


Copyright © Jinan USR IOT Technology Limited. All Rights Reserved

website: www.usriot.com

Step 2 :

- IP Type select DHCP/Auto IP and press save, and press 「Restart Module」 a 「OK」 , EAA-WSCBSN-1 will be assign a dynamic IP.

Firmware Version : V3014
中文




USR IOT
 -IOT Experts-

Be Honest, Do Best!

Current Status	parameter	help
Local IP Config	<div style="display: flex; justify-content: space-between;"> <div> IP Type: DHCP/AutoIP Static IP: Static IP </div> <div> <input type="text" value="0"/> . <input type="text" value="7"/> </div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div>Submask:</div> <div> <input type="text" value="255"/> . <input type="text" value="255"/> . <input type="text" value="255"/> . <input type="text" value="0"/> </div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div>Gateway:</div> <div> <input type="text" value="192"/> . <input type="text" value="168"/> . <input type="text" value="0"/> . <input type="text" value="1"/> </div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div>Dns Server:</div> <div> <input type="text" value="192"/> . <input type="text" value="168"/> . <input type="text" value="0"/> . <input type="text" value="1"/> </div> </div> <div style="text-align: center; margin-top: 10px;"> <input type="button" value="Save"/> <input type="button" value="Cancel"/> </div>	<ul style="list-style-type: none"> IP type: StaticIP or DHCP StaticIP Module's static ip Submask usually 255.255.255.0 Gateway Usually router's ip address

Copyright © Jinan USR IOT Technology Limited. All Rights Reserved
website: www.usriot.com

Firmware Version : V3014
electric tools



USR
 -IOT Experts-

Be Honest, Do Best!


Current Status	Reboot/Reset	help
Local IP Config	<div style="display: flex; justify-content: space-between; align-items: center;"> <div>Restart Module</div> <div><input type="button" value="Restart Module"/></div> </div>	<ul style="list-style-type: none"> Reboot: Click to make your config take effect

Copyright © Jinan USR IOT Technology Limited. All Rights Reserved
website: www.usriot.com

Step 3 :

- EAA-WSCBSN-1 and computer have connected to the same network (LAN). In EAA-WSCBSN-1 > CTRL Setting > [24]IP Address will show assign IP address. Enter this IP on browser in the computer will connect to EAA-WSCBSN-1.

Firmware Version : V3014



USR IOT
 -IOT Experts-

Be Honest, Do Best!

Current Status	parameter	help
Local IP Config	Module Name: USR-K3	<ul style="list-style-type: none"> Run time: run time means the minutes since latest reboot TX/RX Count: TX/RX count give us a calculation of the total byte we have been received or send.
TTL1	Firmware Revision: 3014	
Web to Serial	Current IP Address: 192.168.0.145	
Misc Config	MAC Address: d8-b0-4c-c1-ff-2d	
Reboot	Run Time: 0day: 0hour: 1min:11	
	TX Count(ETH) : 0 bytes	
	RX Count(ETH) : 0 bytes	
	Conn Status(ETH)A: LISTEN	
	Conn Status(ETH)B: IDLE	

Copyright © Jinan USR IOT Technology Limited. All Rights Reserved
 website: www.usriot.com

Step 4 :

- The setting of TTL1 just follow default setting. Please reference below picture: Baud Rate: 115200bps, operation mode: TCP Server, Local/Remote Port Number: 23.