


SA-6601A(B) TIRE INFLATOR GAUGE



PARTS LIST

No.	Parts No.	Description	Q'ty
1	SA6601A-01	Housing	1
2	SA6601A-02	Air Inlet	1
3	SA6601A-03	O-Ring	1
4	SA6601A-04	Spring	1
5	SA6601A-05	O-Ring	2
6	SA6601A-06	Valve Stem	1
7	SA6601A-07	Valve Seat	1
8	SA6601A-08	O-Ring	3
9	SA6601A-09	Adjusting Cap	1
10	SA6601A-10	O-Ring	1
11	SA6601A-11	Adjusting Seat	1
12	SA6601A-12	Return Spring	1
13	SA6601A-13	Nut	1
14	SA6601A-14	Measuring Tape	1
15	SA6601A-15	Measuring Seat	1
16	SA6601A-16	Gasket	1
17	SA6601A-17	Tube	1
18	SA6601A-18	Trigger	1
19	SA6601A-19	Screw	1

SA-6601A(B)-P-0801A-LC