



All of SUMAKE air nailer & stapler programs are CE standard implied, take easy in your mind. We have four kinds of actuation as the below information & attached video:

			1 <sup>st</sup> shot	2 <sup>nd</sup> shot	REMARK
1		Single fire Please click here for attached video	Touch the work-piece first and press the lever	Repeating the action as 1 <sup>st</sup> shot.	Based on CE standard, the length is more than 25mm then safety device must imply.  ★F18/30& P0.6/30 are not implied. It is because these two models are for Asian market. However if needed, the safety device can employed which the safety device would similar to F18/32.
2	SAFETY DEVICE	Bumper fire Please click here for attached video	Press the lever first and touch the work-piece	No need to release the lever, just keep continuing touch the work-piece.	
3		Sequential fire Please click here for attached video	Press the lever first and touch the work-piece.	Un-touch work-piece& release the lever are needed. Then repeating actions in 1st shot.  *** Mainly used in construction purpose: R-65 / R-100	
4	SIMPLE SAFETY LEVER Please click here for attached video		Rotate the below indicated safety switch and press the lever.	Simply press the lever.  ★ CAUTION: Nail can keep firing even NOT touch the work-piece.	Base on CE standard, the length shorter than 25mm only need safety lever.